

6G SAS NAS System

Hardware Manual

Revision 1.0

Table of Contents

Preface	5
FCC Compliance Statement.....	6
Before You Begin	7
Chapter 1 Introduction.....	8
1.1 Key Features.....	8
1.2 Technical Specifications	9
1.3 RAID Concepts.....	11
1.4 Array Definition	16
1.4.1 Raid Set	16
1.4.2 Volume Set	16
1.5 High Availability	17
1.5.1 Creating Hot Spares.....	17
1.5.2 Hot-Swap Disk Drive Support	17
1.5.3 Hot-Swap Disk Rebuild.....	17
Chapter 2 Installation Overview	18
2.1 Packaging, Shipment and Delivery.....	18
2.2 Unpacking the NAS System.....	18
2.3 Identifying Parts of the NAS System.....	19
2.3.1 Front View.....	19
2.3.1.1 Disk Trays	20
2.3.1.2 LCD Front Panel	21
2.3.2 Rear View.....	23
Chapter 3 Getting Started with the NAS System.....	25
3.1 Connecting the NAS to your Network	25
3.2 Powering On	25
3.3 Installing Hard Drives	26
3.3.1 Installing 3.5" Disk in a Disk Tray	26
3.3.2 Installing 2.5" Disk in a Disk Tray	27
Chapter 4 RAID Configuration Utility Options	29
4.1 Configuration through Telnet.....	29
4.1.1 Menu Diagram	34
4.2 Configuration through web browser-based proRAID Manager.....	40
Chapter 5 RAID Management.....	42

5.1	Quick Function.....	42
5.1.1	Quick Create	42
5.2	RAID Set Functions	44
5.2.1	Create RAID Set.....	44
5.2.2	Delete RAID Set.....	45
5.2.3	Expand RAID Set	46
5.2.4	Offline RAID Set	48
5.2.5	Rename RAID Set	49
5.2.6	Activate Incomplete RAID Set	50
5.2.7	Create Hot Spare	52
5.2.8	Delete Hot Spare	53
5.2.9	Rescue Raid Set.....	53
5.3	Volume Set Function.....	54
5.3.1	Create Volume Set	54
5.3.2	Create Raid 30/50/60.....	57
5.3.3	Delete Volume Set	58
5.3.4	Modify Volume Set.....	59
5.3.4.1	Volume Set Expansion	60
5.3.4.2	Volume Set Migration	61
5.3.5	Check Volume Set	61
5.3.6	Schedule Volume Check.....	62
5.3.7	Stop Volume Check.....	64
5.4	Physical Drive.....	65
5.4.1	Create Pass-Through Disk	65
5.4.2	Modify a Pass-Through Disk	66
5.4.3	Delete Pass-Through Disk	67
5.4.4	Identify Enclosure	68
5.4.5	Identify Selected Drive	69
5.5	System Controls	70
5.5.1	System Configuration	70
5.5.2	HDD Power Management.....	72
5.5.3	EtherNet Configuration	74
5.5.4	Alert By Mail Configuration	75
5.5.5	SNMP Configuration	76
5.5.6	NTP Configuration.....	77
5.5.7	View Events / Mute Beeper	78
5.5.8	Generate Test Event	79
5.5.9	Clear Event Buffer	80
5.5.10	Modify Password	81
5.5.11	Upgrade Firmware	82

5.5.12	Shutdown Controller	84
5.5.13	Restart Controller	85
5.6	Information Menu	86
5.6.1	RAID Set Hierarchy	86
5.6.2	System Information	88
5.6.3	Hardware Monitor	89

Preface

About this manual

This manual provides information regarding the hardware features, installation and configuration of the **SAS NAS System**. Information contained in the manual has been reviewed for accuracy, but not for product warranty because of the various environment/OS/settings. Information and specifications will be changed without further notice. Some pictures and screenshots might be different with the actual machine.

This manual uses section numbering for every topic being discussed for easy and convenient way of finding information in accordance with the user's needs. The following icons are being used for some details and information to be considered in going through with this manual:



NOTES:

These are notes that contain useful information and tips that the user must give attention to in going through with the subsystem operation.



IMPORTANT!

These are the important information that the user must remember.



WARNING!

These are the warnings that the user must follow to avoid unnecessary errors and bodily injury during hardware and software operation of the subsystem.



CAUTION:

These are the cautions that user must be aware of to prevent damage to the equipment and its components.

Copyright

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent.

Trademarks

All products and trade names used in this document are trademarks or registered trademarks of their respective owners.

Changes

The material in this document is for information only and is subject to change without notice.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television equipment reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna
2. Move the equipment away from the receiver
3. Plug the equipment into an outlet on a circuit different from that to which the receiver is powered.
4. Consult the dealer or an experienced radio/television technician for help

All external connections should be made using shielded cables



Before You Begin

Before going through with this manual, you should read and focus on the following safety guidelines. Information about the NAS system's packaging and delivery are also included. To provide reasonable protection against any harm on the part of the user and to obtain maximum performance, user is advised to be aware of the following safety guidelines particularly in handling hardware components:

Upon receiving of the product:

- ❖ Place the product in its proper location.
- ❖ To avoid unnecessary dropping out, make sure that somebody is around for immediate assistance.
- ❖ It should be handled with care to avoid dropping that may cause damage to the product. Always use the correct lifting procedures.

Upon installing of the product:

- ❖ Ambient temperature is very important for the installation site. It must not exceed 30°C. Due to seasonal climate changes; regulate the installation site temperature making it not to exceed the allowed ambient temperature.
- ❖ Before plugging-in any power cords, cables and connectors, make sure that the power switches are turned off. Disconnect first any power connection if the power supply module is being removed from the enclosure.
- ❖ Outlets must be accessible to the equipment.
- ❖ All external connections should be made using shielded cables and as much as possible should not be performed by bare hand. Using anti-static hand gloves is recommended.
- ❖ In installing each component, secure all the mounting screws and locks. Make sure that all screws are fully tightened. Follow correctly all the listed procedures in this manual for reliable performance.

Controller Configuration

This NAS system supports single RAID controller configuration.

Packaging, Shipment and Delivery

- ❖ Before removing the subsystem from the shipping carton, you should visually inspect the physical condition of the shipping carton.
- ❖ Unpack and verify that the contents of the shipping carton are complete and in good condition.
- ❖ Exterior damage to the shipping carton may indicate that the contents of the carton are damaged.
- ❖ If any damage is found, do not remove the components; contact the dealer where you purchased the subsystem for further instructions.

Chapter 1 Introduction



The NAS System

1.1 Key Features

- Configurable to 19" rack-mountable 2U chassis
- Supports up to Twelve (12) 2.5" and 3.5" hot-swappable 6G SAS/SATA hard drives
- Supports RAID levels 0, 1, 10(1E), 3, 5, 6, 50, 60 and JBOD
- Support two Gigabit Ethernet port for NAS file-sharing application
- Support one SAS port for direct access of RAID host connection
- Maximal support up to 192 6G SAS/SATA disks totally based on:
 - * Support one SAS Expansion port to connect up to 7 SAS JBOD enclosures for RAID expansion (up to 96 disks)
 - * Support one SAS HBA port to connect second DAS enclosure to expand the RAID of NAS (max. 96 disks with 1RAID + 7 JBOD enclosures)
- Supports hot spare and automatic hot rebuild.
- Allows online capacity expansion within the enclosure

1.2 Technical Specifications

Hardware Platform
Intel Quad Core Xeon 1.8G or above, single / dual Processor
Cache memory : 8GB DDR3 SDRAM up to 144GB
Two Gigabit Ethernet ports (10 Gigabit Ethernet for options)
Up to Twelve 2.5"/3.5" hot-swappable 6Gb/s SAS/SATA hard drives
Real-time drive activity and status indicators
Environmental monitoring unit
Two(2) 460W 80plus hot-swappable power supplies with PFC
Optional: Two(2) 550W 80plus hot-swappable power supplies with PFC for dual processor
Spare PCI-E slot for H/W upgrade
One(1) 4x SAS host port for RAID host connection
One(1) 4x SAS port for JBOD (up to 7 SAS JBOD enclosures, max. 96 disks)
One(1) 4x SAS HBA port for DAS connection (max. 96 disks with 1 RAID + 7 JBOD enclosures)
RAID Controller Specifications
800MHz RAID-On-Chip storage processor
Support RAID level: RAID 0, 1, 10(1E), 3, 5, 6, 50, 60 and JBOD
Onboard 2GB ECC/Registered cache memory
Support drive hot spare and automatic hot rebuild
Support MAID (spin down drives when not in use)
Allow online capacity expansion within the enclosure
Locally audible event notification alarm
800MHz RAID-On-Chip storage processor
Physical Dimension
88(H) x 482(W) x 620(D)mm

Power requirements
AC 100V ~ 240V Full range
10A ~ 5A, 47~63Hz
Environmental
Relative humidity : 10%~85% Non-condensing
Operating temp : 10°C~40°C(50°F~104°F)

***Specification is subject to change without notice.
All company and product names are trademarks of their respective owners.***

1.3 RAID Concepts

RAID Fundamentals


The basic idea of RAID (Redundant Array of Independent Disks) is to combine multiple inexpensive disk drives into an array of disk drives to obtain performance, capacity and reliability that exceeds that of a single large drive. The array of drives appears to the host computer as a single logical drive.

Five types of array architectures, RAID 1 through RAID 5, were originally defined; each provides disk fault-tolerance with different compromises in features and performance. In addition to these five redundant array architectures, it has become popular to refer to a non-redundant array of disk drives as a RAID 0 arrays.

Disk Striping

Fundamental to RAID technology is striping. This is a method of combining multiple drives into one logical storage unit. Striping partitions the storage space of each drive into stripes, which can be as small as one sector (512 bytes) or as large as several megabytes. These stripes are then interleaved in a rotating sequence, so that the combined space is composed alternately of stripes from each drive. The specific type of operating environment determines whether large or small stripes should be used.


Most operating systems today support concurrent disk I/O operations across multiple drives. However, in order to maximize throughput for the disk subsystem, the I/O load must be balanced across all the drives so that each drive can be kept busy as much as possible. In a multiple drive system without striping, the disk I/O load is never perfectly balanced. Some drives will contain data files that are frequently accessed and some drives will rarely be accessed.




By striping the drives in the array with stripes large enough so that each record falls entirely within one stripe, most records can be evenly distributed across all drives. This keeps all drives in the array busy during heavy load situations. This situation allows all drives to work concurrently on different I/O operations, and thus maximize the number of simultaneous I/O operations that can be performed by the array.

Definition of RAID Levels


RAID 0 is typically defined as a group of striped disk drives without parity or data redundancy. RAID 0 arrays can be configured with large stripes for multi-user environments or small stripes for single-user systems that access long sequential records. RAID 0 arrays deliver the best data storage efficiency and performance of any array type. The disadvantage is that if one drive in a RAID 0 array fails, the entire array fails.




RAID 1, also known as disk mirroring, is simply a pair of disk drives that store duplicate data but appear to the computer as a single drive. Although striping is not used within a single mirrored drive pair, multiple RAID 1 arrays can be striped together to create a single large array consisting of pairs of mirrored drives. All writes must go to both drives of a mirrored pair so that the information on the drives is kept identical. However, each individual drive can perform simultaneous, independent read operations. Mirroring thus doubles the read performance of a single non-mirrored drive and while the write performance is unchanged. RAID 1 delivers the best performance of any redundant array type. In addition, there is less performance degradation during drive failure than in RAID 5 arrays.



RAID 3 sector-stripes data across groups of drives, but one drive in the group is dedicated for storing parity information. RAID 3 relies on the embedded ECC in each sector for error detection. In the case of drive failure, data recovery is accomplished by calculating the exclusive OR (XOR) of the information recorded on the remaining drives. Records typically span all drives, which optimizes the disk transfer rate. Because each I/O request accesses every drive in the array, RAID 3 arrays can satisfy only one I/O request at a time. RAID 3 delivers the best performance for single-user, single-tasking environments with long records. Synchronized-spindle drives are required for RAID 3 arrays in order to avoid performance degradation with short records. RAID 5 arrays with small stripes can yield similar performance to RAID 3 arrays.




Under **RAID 5** parity information is distributed across all the drives. Since there is no dedicated parity drive, all drives contain data and read operations can be overlapped on every drive in the array. Write operations will typically access one data drive and one parity drive. However, because different records store their parity on different drives, write operations can usually be overlapped.



Dual-level RAID achieves a balance between the increased data availability inherent in RAID 1 and RAID 5 and the increased read performance inherent in disk striping (RAID 0). These arrays are sometimes referred to as RAID 0+1 or RAID 1+0 and RAID 0+5 or RAID 50.

RAID 6 is similar to RAID 5 in that data protection is achieved by writing parity information to the physical drives in the array. With RAID 6, however, **two** sets of parity data are used. These two sets are different, and each set occupies a capacity equivalent to that of one of the constituent drives. The main advantage of RAID 6 is High data availability – any two drives can fail without loss of critical data.



In summary:

- RAID 0 is the fastest and most efficient array type but offers no fault-tolerance. RAID 0 requires a minimum of one drive.
- RAID 1 is the best choice for performance-critical, fault-tolerant environments. RAID 1 is the only choice for fault-tolerance if no more than two drives are used.
- RAID 3 can be used to speed up data transfer and provide fault-tolerance in single-user environments that access long sequential records. However, RAID 3 does not allow overlapping of multiple I/O operations and requires synchronized-spindle drives to avoid performance degradation with short records. RAID 5 with a small stripe size offers similar performance.
- RAID 5 combines efficient, fault-tolerant data storage with good performance characteristics. However, write performance and performance during drive failure is slower than with RAID 1. Rebuild operations also require more time than with RAID 1 because parity information is also reconstructed. At least three drives are required for RAID 5 arrays.
- RAID 6 is essentially an extension of RAID level 5 which allows for additional fault tolerance by using a second independent distributed parity scheme (two-dimensional parity). Data is striped on a block level across a set of drives, just like in RAID 5, and a second set of parity is calculated and written across all the drives; RAID 6 provides for an extremely high data fault tolerance and can sustain multiple simultaneous drive failures. It is a perfect solution for mission critical applications.

RAID Management

The subsystem can implement several different levels of RAID technology. RAID levels supported by the subsystem are shown below.

RAID Level	Description	Min. Drives
0	Block striping is provide, which yields higher performance than with individual drives. There is no redundancy.	1
1	Drives are paired and mirrored. All data is 100% duplicated on an equivalent drive. Fully redundant.	2
3	Data is striped across several physical drives. Parity protection is used for data redundancy.	3
5	Data is striped across several physical drives. Parity protection is used for data redundancy.	3
6	Data is striped across several physical drives. Parity protection is used for data redundancy. Requires N+2 drives to implement because of two-dimensional parity scheme.	4
1+0 (1E)	Combination of RAID levels 1 and 0. This level provides redundancy through mirroring and striping. RAID 1+0 requires the use of an <u>even number</u> of disk drives to achieve data protection, while RAID 1E (Enhanced Mirroring) uses an <u>odd number</u> of drives. The RAID level shown will still be "1+0" where there is odd number of drives.	4 (3)
30	Combination of RAID levels 0 and 3. This level is best implemented on two RAID 3 disk arrays with data striped across both disk arrays.	6
50	RAID 50 provides the features of both RAID 0 and RAID 5. RAID 50 includes both parity and disk striping across multiple drives. RAID 50 is best implemented on two RAID 5 disk arrays with data striped across both disk arrays.	6
60	RAID 60 combines both RAID 6 and RAID 0 features. Data is striped across disks as in RAID 0, and it uses double distributed parity as in RAID 6. RAID 60 provides data reliability, good overall performance and supports larger volume sizes. RAID 60 also provides very high reliability because data is still available even if multiple disk drives fail (two in each disk array).	8

1.4 Array Definition

1.4.1 Raid Set


A Raid Set is a group of disk drives containing one or more logical volumes called Volume Sets. It is not possible to have multiple Raid Sets on the same disk drives.

A Volume Set must be created either on an existing Raid Set or on a group of available individual disk drives (disk drives that are not yet a part of a Raid Set). If there are existing Raid Sets with available raw capacity, new Volume Set can be created. New Volume Set can also be created on an existing Raid Set without free raw capacity by expanding the Raid Set using available disk drive(s) which is/are not yet Raid Set member. If disk drives of different capacity are grouped together in a Raid Set, then the capacity of the smallest disk will become the effective capacity of all the disks in the Raid Set.

1.4.2 Volume Set

A Volume Set is seen by the host system as a single logical device. It is organized in a RAID level with one or more physical disks. RAID level refers to the level of data performance and protection of a Volume Set. A Volume Set capacity can consume all or a portion of the raw capacity available in a Raid Set. Multiple Volume Sets can exist on a group of disks in a Raid Set. Additional Volume Sets created in a specified Raid Set will reside on all the physical disks in the Raid Set. Thus each Volume Set on the Raid Set will have its data spread evenly across all the disks in the Raid Set. Volume Sets of different RAID levels may coexist on the same Raid Set.

In the illustration below, Volume 1 can be assigned a RAID 5 level while Volume 0 might be assigned a RAID 0+1 level.



1.5 High Availability

1.5.1 Creating Hot Spares

A hot spare drive is an unused online available drive, which is ready to replace a failed disk drive. In a RAID level 1, 0+1, 3, 5 or 6 Raid Set, any unused online available drive installed but not belonging to a Raid Set can be defined as a hot spare drive. Hot spares permit you to replace failed drives without powering down the system. When the RAID subsystem detects a drive failure, the system will do automatic and transparent rebuild using the hot spare drives. The Raid Set will be reconfigured and rebuilt in the background while the RAID subsystem continues to handle system request. During the automatic rebuild process, system activity will continue as normal, however, the system performance and fault tolerance will be affected.



IMPORTANT: The hot spare must have at least the same or more capacity as the drive it replaces.

1.5.2 Hot-Swap Disk Drive Support

The RAID subsystem has built-in protection circuit to support the replacement of SATA II hard disk drives without having to shut down or reboot the system. The removable hard drive tray can deliver "hot swappable" fault-tolerant RAID solution at a price much less than the cost of conventional SCSI hard disk RAID subsystems. This feature is provided in the RAID subsystem for advance fault tolerant RAID protection and "online" drive replacement.

1.5.3 Hot-Swap Disk Rebuild

The Hot-Swap feature can be used to rebuild Raid Sets with data redundancy such as RAID level 1, 0+1, 3, 5 and 6. If a hot spare is not available, the failed disk drive must be replaced with a new disk drive so that the data on the failed drive can be rebuilt. If a hot spare is available, the rebuild starts automatically when a drive fails. The RAID subsystem automatically and transparently rebuilds failed drives in the background with user-definable rebuild rates. The RAID subsystem will automatically continue the rebuild process if the subsystem is shut down or powered off abnormally during a reconstruction process.







Chapter 2 Installation Overview

2.1 Packaging, Shipment and Delivery

- ❖ Before removing the subsystem from the shipping carton, you should visually inspect the physical condition of the shipping carton.
- ❖ Unpack the subsystem and verify that the contents of the shipping carton are all there and in good condition.
- ❖ Exterior damage to the shipping carton may indicate that the contents of the carton are damaged.
- ❖ If any damage is found, do not remove the components; contact the dealer where you purchased the subsystem for further instructions.

2.2 Unpacking the NAS System

The package contains the following items:

NAS System Unit	
Two (2) power cords	
Two (2) Ethernet LAN cables	
One (1) USB-to-PS/2 converter cable	
Installation Reference Guide	
Spare screws, etc.	

If any of these items are missing or damaged, please contact your dealer or sales representative for assistance.

2.3 Identifying Parts of the NAS System

The illustrations below identify the various parts of the system.


2.3.1 Front View



2.3.1.1 Disk Trays



HDD Status Indicator





Part	Function
HDD Activity LED	This LED will blink blue when the hard drive is being accessed.
HDD Fault LED	Green LED indicates power is on and hard drive status is good for this slot. If hard drive is defective or failed, the LED is Red. LED is off when there is no hard drive.

Lock Indicator

Every Disk Tray is lockable and is fitted with a lock indicator to indicate whether or not the tray is locked into the chassis or not. Each tray is also fitted with an ergonomic handle for easy tray removal.

When the Lock Groove is horizontal, this indicates that the Disk Tray is locked. When the Lock Groove is vertical, then the Disk Tray is unlocked.



2.3.1.2 LCD Front Panel




Front Panel

The LCD front panel is an option to setup some system settings. To start using the LCD panel, press the Select button to login and configure the system. See the LCD menu diagram in the next section.


Parts		Function
Exit button	EXIT	Press this button to return to the previous menu.
Select button	✓	This is used to enter the option you have selected.
Up and Down Arrow buttons	⬆️⬆️	Use the Up or Down arrow keys to go through the information on the LCD screen. This is also used to move between each menu when you configure the system.

Use the function keys to navigate through the menus in the front panel. The menus will show the system status and allows you to configure network settings, password and mute the alarm buzzer.


Menu Diagram



2.3.2 Rear View



1. **Power On/Off Switch** – Use this switch to power on the NAS system. Note that there is a protective cover.
2. **R-Link Port** – The system is equipped with one 10/100 Ethernet RJ45 LAN port for remote RAID configuration and monitoring. Use a web browser to manage the RAID controller through proRAID Manager GUI.
3. **Power Input Socket** - Use this to connect the power cords connected from power source.
4. **Power Supply Unit #1 and #2** – Two power supplies (PSU 1 and PSU 2) are located at the rear of the NAS system.

If the power supply fails to function, the  Power Fail LED will turn red and an alarm will sound. An error message will also appear on the LCD screen warning of power failure.
5. **USB Ports** – The NAS system has four USB 2.0 ports.



NOTE: When connecting PS/2 keyboard and mouse, use the USB-to-PS/2 converter cable, and then insert the USB connector of converter cable to the one of the USB ports of the NAS.

6. **LAN0, and LAN1 Gigabit ports** – The NAS system has two Gigabit data ports.
7. **VGA Port** – Use this to connect a VGA monitor.
8. **COM1 Serial Port** – The NAS system has one serial port.

- 9. SAS Expansion Port** – Use this to connect SAS JBOD expansion enclosures to expand the storage capacity of the NAS. Up to 7 JBOD enclosures can be connected in daisy-chain.
- 10. SAS RAID Host Port** – Use this to connect the RAID subsystem to a Host system's SAS HBA. The host system will detect the RAID volume created from the NAS RAID controller.
- 11. SAS HBA Port** – Use this to connect another SAS RAID subsystem to expand the storage capacity of the NAS. The SAS RAID subsystem can include 6 JBOD enclosures connected in daisy-chain. The NAS will detect all volumes created from the SAS RAID subsystem. (max. 96 disks with 1 RAID + 7 JBOD enclosures)

Chapter 3 Getting Started with the NAS System

3.1 Connecting the NAS to your Network


1. Attach network cable to the Ethernet port LAN0. Connect the other end to your network hub or switch. You may also connect the other Ethernet port if needed.
2. If the RAID controller will be configured using proRAID Manager Web GUI or RAID console (via Telnet), attach network cable to the R-Link port. Connect the other end to your network hub or switch. The RAID controller can also be configured using NAS Device Manager without needing to connect the R-Link port.

3.2 Powering On



NOTE: If other JBOD subsystem(s) or RAID subsystem, with or without JBOD subsystem(s) connected in daisy-chain, are to be connected to the SAS Expansion Port or to the SAS HBA Port respectively, the JBOD subsystems or RAID subsystem (and its JBOD subsystem(s)) must be powered on first before the NAS. This is to detect the disk drives from the JBOD subsystem or the volumes from the RAID subsystem.

1. Plug in the 2 power cords into the AC Power Input Socket located at the rear of the NAS system.



NOTE: The NAS system is equipped with redundant, full range power supplies with PFC (power factor correction). The system will automatically select voltage.

2. Turn on the Power On/Off Switch to power on the NAS.
3. The Power LED on the front Panel will turn green.

3.3 Installing Hard Drives

This section describes the physical locations of the hard drives supported by the subsystem and gives instructions on installing a hard drive. The subsystem supports hot-swapping allowing you to install or replace a hard drive while the subsystem is running.

Each Drive Carrier has a locking mechanism. When the Lock Groove, which is located in carrier open button, is horizontal, the Drive Carrier is locked. When the Lock Groove is vertical, the Drive Carrier is unlocked. Lock and unlock the Drive Carriers by using a flat-head screw driver.

3.3.1 Installing 3.5" Disk in a Disk Tray

- a. Make sure the lock indicator is in unlocked position. To pull out a disk tray, press the tray open button.



- b. Pull out an empty disk tray. Pull the lever handle outwards to remove the carrier from the enclosure.
- c. Place the hard drive in the disk tray.



- d. Install the mounting screws on the bottom part to secure the drive in the disk tray.



Tray Hole A

- e. Slide the tray into a slot.
- f. Close the lever handle until you hear the latch click into place.

3.3.2 Installing 2.5" Disk in a Disk Tray

- a. Make sure the lock indicator is in unlocked position. To pull out a disk tray, press the tray open button.




**Tray
Open
Button**

- b. Pull out an empty disk tray. Pull the lever handle outwards to remove the carrier from the enclosure.

- c. Place the 2.5" hard drive in the disk tray.



- d. Install the mounting screws on the bottom part to secure the drive in the disk tray.



Tray Hole W

- e. Slide the tray into a slot.
f. Close the lever handle until you hear the latch click into place.

Chapter 4 RAID Configuration Utility Options

Configuration Methods

There are three methods of configuring the RAID controller:

- Front panel touch-control buttons
- Web browser-based remote RAID management via the R-Link Ethernet port
- Telnet connection via the R-Link Ethernet port




NOTE: The RAID subsystem allows you to access using only one method at a time. You cannot use more than one method at the same time.

4.1 Configuration through Telnet




NOTE: This example uses CRT terminal emulation program. You can also use Windows Hyper terminal as another option.


- To connect to RAID subsystem using Telnet, open Terminal Emulation program (example, CRT 6.1) and start new session, and select Telnet protocol. Click "Next".




2. Enter the RAID subsystem's IP address. Make sure the PC running the terminal emulation program can connect to the RAID subsystem's IP address. Click "Next".




3. Rename the Session name if necessary. Click "Finish".



4. Select the Session name and click "Connect".



5. After successful connection, the Main Menu will be displayed. Select a menu and the Password box will be shown. Enter password (default is 00000000) to login.




Keyboard Function Key Definitions

- "A" key - to move to the line above
- "Z" key - to move to the next line
- "Enter" key - Submit selection function
- "ESC" key - Return to previous screen
- "L" key - Line draw
- "X" key - Redraw

Main Menu

The main menu shows all function that enables the customer to execute actions by clicking on the appropriate link.



NOTE: The password option allows user to set or clear the RAID subsystem's password protection feature. Once the password has been set, the user can only monitor and configure the RAID subsystem by providing the correct password. The password is used to protect the RAID subsystem from unauthorized access. The controller will check the password only when entering the Main menu from the initial screen. The RAID subsystem will automatically go back to the initial screen when it does not receive any command in twenty seconds. The RAID subsystem's factory default password is set to 00000000.


VT100 terminal configuration Utility Main Menu Options


Select an option and the related information or submenu items display beneath it. The submenus for each item are shown in Section 4.1.1. The configuration utility main menu options are:


Option	Description
Quick Volume And Raid Set Setup	Create a RAID configuration which consists of all physical disks installed
Raid Set Functions	Create a customized Raid Set
Volume Set Functions	Create a customized Volume Set
Physical Drive Functions	View individual disk information
Raid System Functions	Setting the Raid system configurations
Ethernet Configuration	Setting the Ethernet configurations
Views System Events	Record all system events in the buffer
Clear Event Buffer	Clear all event buffer information
Hardware Monitor	Show all system environment status
System Information	View the controller information


4.1.1 Menu Diagram

The following menu diagram is a summary of the various configurations and setting functions that can be accessed through terminal.













Raid System Function

- Mute The Alert Beeper → Yes, No
- Alert Beeper Setting → Disabled, Enabled
 - └ Save The Settings → Yes, No
- Change Password
 - └ Enter New Password
 - └ Re-Enter Password
 - └ Save The Password → Yes, No
- JBOD / RAID Function
 - └ RAID, JBOD
 - └ Configured AS JBOD? → Yes, No
 - └ Are You Sure? → Yes, No
- Background Task Priority → UltraLow(5%), Low(20%)
Medium(50%), High(80%)
 - └ Save The Settings → Yes, No
- SATA NCQ Support → Enable, Disable
 - └ Save the Settings → Yes, No
- HDD Read Ahead Cache → Enable, Disable Maxtor, Disable
 - └ Save the Settings → Yes, No
- Volume Data Read Ahead → Normal, Aggressive, Conservative, Disabled
 - └ Save the Settings → Yes, No
- HDD Queue Depth Setting → 1, 2, 4, 8, 16, 32
 - └ Save the Settings → Yes, No
- Controller Fan Detection → Disabled, Enabled
 - └ Save the Settings → Yes, No
- Disk Write Cache Mode → Auto, Enabled, Disabled
 - └ Save the Settings → Yes, No
- Capacity Truncation → To Multiples of 10G,
To Multiples of 1G, Disabled
 - └ Save the Settings → Yes, No
- Update Firmware
- Shutdown Controller
 - └ Shutdown Controller → Yes, No
 - └ Are You Sure → Yes, No
- Restart Controller
 - └ Confirm Reset → Yes, No
 - └ Are You Sure → Yes, No



4.2 Configuration through web browser-based proRAID Manager

The RAID subsystem can be remotely configured via R-Link port with proRAID Manager, a web browser-based application. The proRAID Manager can be used to manage all available functions of the RAID controller.

To configure the RAID subsystem from a remote machine, you need to know its IP Address. Launch your web browser from remote machine and enter in the address bar: **http://[IP Address]**.



IMPORTANT! The default IP address of Controller R-Link Port is 172.16.0.2 and subnet mask is 255.255.255.0. DHCP client function is also enabled by default. You can reconfigure the IP Address or disable the DHCP client function through the LCD front panel or terminal "Ethernet Configuration" menu.



NOTE: If DHCP client function is enabled but a DHCP server is unavailable and the IP address is changed, a Controller Restart is necessary. If the DHCP client function is disabled and the IP address is changed, Controller Restart is not needed.

Note that you may need to be logged in as administrator with local admin rights on the remote machine to remotely configure the RAID subsystem. The RAID subsystem controller default User Name is "admin" and the Password is "00000000".

open all close all				
<div><div>Raid System Console</div><div><div>Quick Function</div><div>RAID Set Functions</div><div>Volume Set Functions</div><div>Physical Drives</div><div>System Controls</div><div>Information</div><div><div>RAID Set Hierarchy</div><div>System Information</div><div>Hardware Monitor</div></div></div></div>				
■ RAID Set Hierarchy				
RAID Set	Devices	Volume Set(Port/Lun)	Volume State	Capacity
Raid Set # 000	E#1Slot#1	Volume---VOL#000(0/0)	Normal	2199.0GB
	E#1Slot#2			
	E#1Slot#3			
	E#1Slot#4			
	E#1Slot#5			
	E#1Slot#6			
Raid Set # 001	E#1Slot#7	Volume---VOL#001(1/0)	Normal	2199.0GB
	E#1Slot#8			
	E#1Slot#9			
	E#1Slot#10			
	E#1Slot#11			
	E#1Slot#12			
■ Enclosure#1 : SAS RAID Subsystem V1.0				
Device	Usage	Capacity	Model	
Slot#1(12)	Raid Set # 000	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#2(13)	Raid Set # 000	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#3(10)	Raid Set # 000	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#4(15)	Raid Set # 000	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#5(14)	Raid Set # 000	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#6(15)	Raid Set # 000	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#7(18)	Raid Set # 001	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#8(16)	Raid Set # 001	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#9(16)	Raid Set # 001	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#10(17)	Raid Set # 001	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#11(18)	Raid Set # 001	600.1GB	WDC WD6000HLHX-01JJPV0	
Slot#12(19)	Raid Set # 001	600.1GB	WDC WD6000HLHX-01JJPV0	

Main Menu

The main menu shows all available function that user can execute by clicking on the appropriate hyperlink.

Individual Category	Description
Quick Function	Create a RAID configuration, which consists of all physical disks installed. The Volume Set Capacity, Raid Level, and Stripe Size can be modified during setup.
Raid Set Functions	Create customized Raid Sets.
Volume Set Functions	Create customized Volume Sets and allow modification of parameters of existing Volume Sets parameter.
Physical Drive	Create pass through disks and allow modification of parameters of existing pass through drives. This also provides a function to identify a disk drive.
System Control	For setting the RAID system configurations.
Information	To view the controller and hardware monitor information. The Raid Set hierarchy can also be viewed through the Raid Set Hierarchy item.

Chapter 5 RAID Management

5.1 Quick Function

5.1.1 Quick Create

The number of physical drives in the RAID subsystem determines the RAID levels that can be implemented with the Raid Set. This feature allows user to create a Raid Set associated with exactly one Volume Set. User can change the Raid Level, Capacity, Volume Initialization Mode and Stripe Size. A hot spare can also be created depending upon the existing configuration.

If the Volume Set size is over 2TB, an option "Greater Two TB Volume Support" will be automatically provided in the screen as shown in the example below. There are three options to select: "No", "64bit LBA", and "4K Block").

The screenshot shows the 'proRAID Manager' interface with a sidebar on the left containing a tree view with items like 'Raid System Console', 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', and 'Information'. The 'Quick Create' option is selected. The main panel is titled 'Quick Create Raid/Volume Set' and contains the following fields:

Total Number Of Disks	8
Select Raid Level	Raid 5 + Spare
Maximum Capacity Allowed	6000 GB
Select Capacity	6000 GB
Greater Two TB Volume Support	No
Volume Initialization Mode	Foreground Initialization
Select Stripe Size	64 KBytes

Below these fields is a checkbox labeled 'Confirm The Operation'. At the bottom are 'Submit' and 'Reset' buttons.

Greater Two TB Volume Support:

No: Volume Set capacity is set to maximum 2TB.

64bit LBA: Use this option for UNIX, Linux 2.6, and Windows Server 2003 + SP1 or later versions. The maximum Volume Set size is up to 512TB.

4K Block: Use this option for Windows OS such as Windows 2000, 2003, or XP. The maximum Volume Set size is 16TB. Just use the Volume as "Basic Disk". Volume can't be used as "Dynamic Disk"; also can't be used in 512Bytes block service program.

Tick on the **Confirm The Operation** option and click on the **Submit** button in the Quick Create screen. The Raid Set and Volume Set will start to initialize.

You can use **RaidSet Hierarchy** feature to view the Volume Set information (Refer to Section 5.6.1).



NOTE: In Quick Create your Raid Set is automatically configured based on the number of disks in your system. Use the Raid Set Function and Volume Set Function if you prefer to customize the Raid Set and Volume Set.

5.2 RAID Set Functions

Use the Raid Set Function and Volume Set Function if you prefer to create customized Raid Sets and Volume Sets. User can manually configure and take full control of the Raid Set settings, but it will take a little longer to setup than the Quick Create configuration. Select the Raid Set Function to manually configure the Raid Set for the first time or to delete existing Raid Set and reconfigure a Raid Set.

5.2.1 Create RAID Set

The screenshot displays the RAID System Console interface. On the left is a sidebar with a tree view containing the following items: 'Raid System Console', 'Quick Function', 'RAID Set Functions' (expanded), 'Volume Set Functions', 'Physical Drives', 'System Controls', and 'Information'. Under 'RAID Set Functions', the 'Create RAID Set' option is selected and highlighted. The main area is titled 'Select The Drives For RAID Set' and shows 'Enclosure# 1 : SAS RAID Subsystem V1.0'. It contains a table of disk drives with checkboxes for selection. Below the table is a text field for 'Raid Set Name' with the value 'Raid Set #000'. At the bottom, there is a 'Confirm The Operation' checkbox and 'Submit' and 'Reset' buttons.

■ Select The Drives For RAID Set			
■ Enclosure# 1 : SAS RAID Subsystem V1.0			
<input type="checkbox"/>	Slot#1	1000.2GB	Hitachi HDE721010SLA330
<input type="checkbox"/>	Slot#2	1000.2GB	Hitachi HDE721010SLA330
<input type="checkbox"/>	Slot#3	1000.2GB	Hitachi HDE721010SLA330
<input type="checkbox"/>	Slot#4	1000.2GB	Hitachi HDE721010SLA330
<input type="checkbox"/>	Slot#5	1000.2GB	Hitachi HDE721010SLA330
<input type="checkbox"/>	Slot#6	1000.2GB	Hitachi HDE721010SLA330
<input type="checkbox"/>	Slot#7	1000.2GB	Hitachi HDE721010SLA330
<input type="checkbox"/>	Slot#8	1000.2GB	Hitachi HDE721010SLA330

Raid Set Name:

☐ **Confirm The Operation**

To create a Raid Set, click on the **Create RAID Set** link. A "Select The Drives For RAID Set" screen is displayed showing the disk drives in the system. Tick the box of each disk drive that will be included in Raid Set to be created. Enter the preferred Raid Set Name (1 to 16 alphanumeric characters) to define a unique identifier for the Raid Set. The default Raid Set name will always appear as **Raid Set # xxx**.

Tick on the **Confirm The Operation** option and click on the **Submit** button in the screen.

5.2.2 Delete RAID Set

To delete a Raid Set, click on the **Delete RAID Set** link. A "Select The RAID SET To Delete" screen is displayed showing all Raid Sets existing in the system. Select the Raid Set you want to delete in the Select column.

Tick on the **Confirm The Operation** and click on the **Submit** button to process with deletion.



open all | close all |

- Raid System Console
 - Quick Function
 - RAID Set Functions
 - Create RAID Set
 - Delete RAID Set**
 - Expand RAID Set
 - Offline RAID Set
 - Rename RAID Set
 - Activate Incomplete RAID Set
 - Create Hot Spare
 - Delete Hot Spare
 - Rescue Raid Set
 - Volume Set Functions
 - Physical Drives
 - System Controls
 - Information

Select	Raid Set Name	Member Disks	Raid State	Capacity
<input checked="" type="radio"/>	Raid Set # 000	8/8	Normal	8000.0GB


☒ **Confirm The Operation, VolumeSet In This RaidSet Will Also Be Deleted**



NOTE: You cannot delete a Raid Set containing a Raid 30/50/60 Volume Set. You must delete the Raid 30/50/60 Volume Set first.

5.2.3 Expand RAID Set

Use this option to expand a Raid Set, when one or more disk drives is/are added to the system. This function is active when at least one drive is available.



To expand a Raid Set, click on the **Expand RAID Set** link. Select the Raid Set which you want to expand.

Tick on the available disk(s) and check **Confirm The Operation**. Click on the **Submit** button to add the selected disk(s) to the Raid Set.




NOTE: Once the Expand Raid Set process has started, user cannot stop it. The process must be completed.





NOTE: If a disk drive fails during Raid Set expansion and a hot spare is available, an auto rebuild operation will occur after the Raid Set expansion is completed.




NOTE: A Raid Set cannot be expanded if it contains a Raid 30/50/60 Volume Set.





Migration occurs when a disk is added to a Raid Set. Migrating status is displayed in the Raid Set status area of the Raid Set information. Migrating status is also displayed in the Volume Set status area of the Volume Set Information for all Volume Sets under the Raid Set which is migrating.



5.2.4 Offline RAID Set

If user wants to offline (and move) a Raid Set while the system is powered on, use the Offline Raid Set function. After completing the function, the HDD state of RAID Set member drives will change to "Offlined" Mode and the HDD Status LEDs will be blinking RED.

To offline a Raid Set, click on the **Offline RAID Set** link. A "Select The RAID SET To Offline" screen is displayed showing all existing Raid Sets in the subsystem. Select the Raid Set which you want to offline in the Select column.

Tick on the **Confirm The Operation**, and then click on the **Submit** button.

open all|close all|

Raid System Console

- Quick Function
- RAID Set Functions
 - Create RAID Set
 - Delete RAID Set
 - Expand RAID Set
 - Offline RAID Set
 - Rename RAID Set
 - Activate Incomplete RAID Set
 - Create Hot Spare
 - Delete Hot Spare
 - Rescue Raid Set
- Volume Set Functions
- Physical Drives
- System Controls
- Information

■ Select The Raid Set To Offline

Select	Raid Set Name	Member Disks	Raid State	Capacity
<input type="radio"/>	Raid Set # 000	6/6	Normal	6000.0GB

☒ Confirm The Operation, VolumeSet In This RaidSet Will Also Be Offlined

Submit Reset

open all|close all|

Raid System Console

- Quick Function
- RAID Set Functions
- Volume Set Functions
- Physical Drives
- System Controls
- Information
 - RAID Set Hierarchy
 - System Information
 - Hardware Monitor

■ RaidSet Hierarchy

RAID Set	Devices	Volume Set(Ch/Lun)	Volume State	Capacity
----------	---------	--------------------	--------------	----------

■ Enclosure# 1 : SAS RAID Subsystem V1.0

Device	Usage	Capacity	Model
Slot#1(12)	Offlined	1000.2GB	Hitachi HDE721010SLA330
Slot#2(14)	Offlined	1000.2GB	Hitachi HDE721010SLA330
Slot#3(19)	Offlined	1000.2GB	Hitachi HDE721010SLA330
Slot#4(1A)	Offlined	1000.2GB	Hitachi HDE721010SLA330
Slot#5(15)	Offlined	1000.2GB	Hitachi HDE721010SLA330
Slot#6(16)	Offlined	1000.2GB	Hitachi HDE721010SLA330
Slot#7(17)	Free	1000.2GB	Hitachi HDE721010SLA330
Slot#8(18)	Free	1000.2GB	Hitachi HDE721010SLA330
Slot#9	N.A.	N.A.	N.A.
Slot#10	N.A.	N.A.	N.A.
Slot#11	N.A.	N.A.	N.A.
Slot#12	N.A.	N.A.	N.A.
Slot#13	N.A.	N.A.	N.A.
Slot#14	N.A.	N.A.	N.A.
Slot#15	N.A.	N.A.	N.A.
Slot#16	N.A.	N.A.	N.A.

5.2.5 Rename RAID Set

Use this function to rename a RAID Set. Select the **"Rename RAID Set"** under the RAID Set Functions, and then select the RAID Set to rename and click **"Submit"**.

The screenshot shows the RAID System Console interface. On the left, a tree view under 'RAID Set Functions' has 'Rename RAID Set' selected. The main panel displays a table titled 'Select The Raid Set To Rename' with the following data:

Select	Raid Set Name	Member Disks	Raid State	Capacity
<input checked="" type="radio"/>	Raid Set # 000	6/6	Normal	6000.0GB

Below the table are 'Submit' and 'Reset' buttons.

Enter the new name for the RAID Set. Tick the **"Confirm The Operation"** and click **"Submit"**.

The screenshot shows the RAID System Console interface. On the left, 'Rename RAID Set' is selected. The main panel displays a form titled 'Enter The RaidSet Name' with the following fields:

Raid Set Name	<input type="text" value="Raid Set #000"/>
Member Disks	<input type="text" value="6"/>
Min Member Disk Size	<input type="text" value="1000.0GB"/>

Below the fields is a checkbox labeled 'Confirm The Operation' (which is checked) and 'Submit' and 'Reset' buttons.

5.2.6 Activate Incomplete RAID Set

When Raid Set State is “**Normal**”, this means there is no failed disk drive.

■ Raid Set Information	
Raid Set Name	Raid Set # 000
Member Disks	10
Total Raw Capacity	3200.0GB
Free Raw Capacity	756.7GB
Min Member Disk Size	320.0GB
Raid Set Power State	Operating
Raid Set State	Normal

When does “Incomplete” Raid Set State Happens?

If the RAID subsystem is powered off and one disk drive is removed or has failed in power off state, and when the subsystem is powered on, the Raid Set State will change to “**Incomplete**”.


■ Raid Set Information	
Raid Set Name	Raid Set # 000
Member Disks	10
Total Raw Capacity	3200.0GB
Free Raw Capacity	3200.0GB
Min Member Disk Size	320.0GB
Raid Set Power State	Operating
Raid Set State	Incomplete

The Volume Set will not be visible and the failed or removed disk will be shown as “**Missing**”. At the same time, the Host system will not detect the Volume Set, hence the volumes are not accessible.

When can the “Activate Incomplete RAID Set” function be used?

In order to access the Volume Set and corresponding data, use the **Activate Incomplete RAID Set** function to activate the Raid Set. After selecting this function, the Raid State will change to “**Degraded**” state.

To activate the incomplete the Raid Set, click on the **Activate Incomplete RAID Set** link. A “Select The Raid Set To Activate” screen is displayed showing all existing Raid Sets in the subsystem. Select the Raid Set with “**Incomplete**” state which you want to activate in the Select column.



Click on the **Submit** button to activate the Raid Set. The Volume Set(s) associated with the Raid Set will become accessible in “**Degraded**” mode.



NOTE: The “Activate Incomplete RAID Set” function is only used when Raid Set State is “Incomplete”. It cannot be used when Raid Set configuration is lost. In case Raid Set configuration is lost, contact your vendor for support.

5.2.7 Create Hot Spare

When you choose the **Create Hot Spare** option in the Raid Set Function, all unused (non Raid Set member) disk drives in the subsystem appear. Select the target disk drive by clicking on the appropriate check box. Select the Hot Spare Type. Tick on the **Confirm The Operation** and click on the **Submit** button to create hot spare drive(s).

The screenshot shows the RAID System Console interface. On the left is a tree view with categories: RAID System Console, Quick Function, RAID Set Functions, Volume Set Functions, Physical Drives, System Controls, and Information. Under RAID Set Functions, 'Create Hot Spare' is selected. The main window is titled 'Select The Drives For Hot Spare'. It shows 'Enclosure# 1 : SAS E x28-05.89.1.39 000'. Below this is a table with columns for Slot, Capacity, and Model. Two slots are checked: SLOT 08 (500.1GB, WDC WD5000BEVT-00A03T0) and SLOT 09 (500.1GB, ST9500325AS). Below the table is a dropdown for 'Select The Hot Spare Type' with options: Global Hot Spare, Dedicated To RaidSet, and Dedicated To Enclosure. A checkbox labeled 'Confirm The Operation' is checked. At the bottom are 'Submit' and 'Reset' buttons.

Hot Spare Type	Description
Global Hot Spare	The Hot Spare disk is a hot spare on all enclosures connected in daisy chain. It can replace any failed disk in any enclosure.
Dedicated to RaidSet	The Hot Spare disk is a hot spare dedicated only to the RaidSet where it is assigned. It can replace any failed disk in the RaidSet where it is assigned.
Dedicated to Enclosure	The Hot Spare disk is a hot spare dedicated only to the enclosure where it is located. It can replace any failed disk on the enclosure where it is located.



NOTE: The Hot Spare Type can also be viewed by clicking on **Raid Set Hierarchy** in the **Information** menu.

5.2.8 Delete Hot Spare

Select the target Hot Spare disk(s) to delete by clicking on the appropriate check box.

Tick on the **Confirm The Operation**, and click on the **Submit** button in the screen to delete the hot spare(s).

The screenshot shows the RAID System Console interface. On the left, a tree view under 'RAID Set Functions' has 'Delete Hot Spare' selected. The main panel is titled 'Select The Hot Spare Drive To Delete'. It shows 'Enclosure# 1 : SAS RAID Subsystem V1.0' with a table listing drives. The first row is selected, showing 'Slot#8', '1000.2GB', and 'Hitachi HDE721010SLA330 [Global]'. Below the table, the 'Confirm The Operation' checkbox is checked. At the bottom are 'Submit' and 'Reset' buttons.

Slot#	Capacity	Model
Slot#8	1000.2GB	Hitachi HDE721010SLA330 [Global]

5.2.9 Rescue Raid Set

If you need to recover missing Raid Set configuration using the "Rescue Raid Set" function, please contact your vendor's support engineer for assistance.

The screenshot shows the RAID System Console interface. On the left, a tree view under 'RAID Set Functions' has 'Rescue Raid Set' selected. The main panel is titled 'Try To Rescue Missing RAIDSET'. It contains instructions: 'Enter 'RESCUE' To Try To Recover Missing RaidSet' and 'Enter 'SIGNAT' To Regenerate RaidSet Signature If RaidSet Is Recovered'. Below this is a text input field with the placeholder 'Enter The Keyword'. The 'Confirm The Operation' checkbox is unchecked. At the bottom are 'Submit' and 'Reset' buttons.

5.3 Volume Set Function

Volume Set is seen by the host system as a single logical device. It is organized in a RAID level with one or more physical disks. RAID level refers to the level of data performance and protection of a Volume Set. A Volume Set capacity can consume all or a portion of the raw capacity available in a Raid Set. Multiple


Volume Sets can exist on a group of disks in a Raid Set. Additional Volume Sets created in a specified Raid Set will reside on all the physical disks in the Raid Set. Thus each Volume Set on the Raid Set will have its data spread evenly across all the disks in the Raid Set.

5.3.1 Create Volume Set


The following are the Volume Set features:

1. Volume sets of different RAID levels may coexist on the same Raid Set.
2. Up to 128 Volume Sets in a Raid Set can be created by the RAID controller.

To create Volume Set from a Raid Set, expand the Volume Set Functions in the main menu and click on the **Create Volume Set** link. The **Select The Raid Set To Create On It** screen will show all existing Raid Sets. Tick on the Raid Set where you want to create the Volume Set and then click on the **Submit** button.



The Volume Set setup screen allows user to configure the Volume Name, Capacity, RAID level, Initialization Mode, Stripe Size, Cache Mode, Tagged Command Queuing, SAS Port/LUN Base/LUN, and Volume To Be Created.



Volume Name:

The default Volume Set name will appear as "Volume---VOL#XXX". You can rename the Volume Set name provided it does not exceed the 16 characters limit.

Raid Level:

Set the RAID level for the Volume Set. Click the down-arrow in the drop-down list. The available RAID levels for the current Volume Set are displayed. Select the preferred RAID level.

Capacity:

The maximum Volume Set size is displayed by default. If necessary, change the Volume Set size appropriate for your application.

Greater Two TB Volume Support:

If the Volume Set size is over 2TB, an option "Greater Two TB Volume Support" will be automatically provided in the screen as shown in the example above. There are three options to select: "No", "64bit LBA", and "4K Block").

No: Volume Set size is set to maximum 2TB limitation.

64bit LBA: Use this option for UNIX, Linux kernel 2.6 or later, and Windows Server 2003 + SP1 or later versions. The maximum Volume Set size is up to 512TB.

4K Block: Use this option for Windows OS such as Windows 2000, 2003, or XP. The maximum Volume Set size is 16TB. Just use the Volume as "Basic Disk". Volume can't be used as "Dynamic Disk"; also can't be used in 512Bytes block service program.

Initialization Mode:

Set the Initialization Mode for the Volume Set. Initialization in Foreground mode is completed faster but must be completed before Volume Set becomes accessible. Background mode makes the Volume Set instantly available but the initialization process

takes longer. No Init (To Rescue Volume) is used to create a Volume Set without initialization; normally used to recreate Volume Set configuration to recover data.

Stripe Size:

This parameter sets the size of the stripe written to each disk in a RAID 0, 1, 10, 5 or 6 Volume Set. You can set the stripe size to 4 KB, 8 KB, 16 KB, 32 KB, 64 KB, or 128 KB.

A larger stripe size produces better-read performance, especially if your computer does mostly sequential reads. However, if you are sure that your computer does random reads more often, select a small stripe size.



NOTE Stripe Size in RAID level 3 can't be modified.

Cache Mode:

The RAID subsystem supports two types of write caching: Write-Through and Write-Back.

Write-Through: data are both written to the cache and the disk(s) before the write I/O is acknowledged as complete.

Write-Back: when data is written to cache, the I/O is acknowledged as complete, and some time later, the cached data is written or flushed to the disk(s). This provides better performance but requires a battery module support for the cache memory, or a UPS for the subsystem.

Tagged Command Queuing:

When this option is enabled, it enhances the overall system performance under multi-tasking operating systems by reordering tasks or requests in the command queue of the RAID system. This function should normally remain enabled.

SAS Port/LUN Base/LUN:

SAS Port: Each RAID controller has two 6Gbps SAS Host Channels (ports). Select the SAS port where to map the LUN (Volume Set). Options are: **0**, **1** and **0&1 Cluster**. **0&1 Cluster** will make the LUN visible on both SAS ports.

LUN Base: The base LUN number. Each LUN Base supports 8 LUNs.

LUN: Each Volume Set must be assigned a unique LUN ID number. A SAS Port can connect up to 128 devices (LUN ID: 0 to 127). Select the LUN ID for the Volume Set.

Volumes To Be Created: Use this option to create several Volume Sets with the same Volume Set attributes. Up to 128 Volume Sets can be created.

5.3.2 Create Raid 30/50/60

To create a Raid30/50/60 Volume Set, move the mouse cursor to the main menu and click on the **Create Raid30/50/60** link. The **Select Multiple RaidSet For Raid30/50/60** screen will show all Raid Sets. Tick on the Raid Sets that you want to include in the creation and then click on the **Submit** button.



NOTE: Maximum of 8 Raid Sets is supported. All Raid Sets must contain the same number of disk drives.

The screenshot shows the proRAID Manager interface. On the left is a tree menu with categories like 'Raid System Console', 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', and 'Information'. The 'Create Raid30/50/60' option is selected under 'Volume Set Functions'. The main panel is titled 'Select Multiple RaidSet For Raid30/50/60 (Max 8 RaidSet Supported)'. It contains a table with two rows of RAID sets, both checked. Below the table are 'Submit' and 'Reset' buttons.

	Raid Set #	Level	Capacity	Size
<input checked="" type="checkbox"/>	Raid Set # 000	3	3000.0GB	3000.0GB
<input checked="" type="checkbox"/>	Raid Set # 001	3	3000.0GB	3000.0GB


Configure the Volume Set attributes (refer to previous section for the Volume Set attributes). When done, tick **Confirm The Operation** and click on **Submit** button.

The screenshot shows the 'Enter The Volume Attribute' screen in proRAID Manager. It features a form with various fields for configuring a volume set. At the bottom, there is a checkbox for 'Confirm The Operation' and 'Submit'/'Reset' buttons.

Volume Name	Volume---VOL#000
Member Disks	2x3
Volume Raid Level	50
Max Capacity Allowed	4000.0 GB
Select Volume Capacity	4000.0 GB
Greater Two TB Volume Support	No
Volume Initialization Mode	Foreground Initialization
Volume Stripe Size	64 KBytes
Volume Cache Mode	Write Back
Tagged Command Queuing	Enabled
SAS Port:LUN Base:LUN	0 : 0 : 0
Volumes To Be Created	1

5.3.3 Delete Volume Set


To delete a Volume Set, select the Volume Set Functions in the main menu and click on the **Delete Volume Set** link. The **Select The Volume Set To Delete** screen will show all available Raid Sets. Tick on a Raid Set and check the **Confirm The Operation** option and then click on the **Submit** button to show all Volume Sets in the selected Raid Set. Tick on a Volume Set and check the **Confirm The Operation** option. Click on the **Submit** button to delete the Volume Set.



5.3.4 Modify Volume Set


Use this function to modify Volume Set configuration.

1. Click on the **Modify Volume Set** link.



2. Tick from the list the Volume Set you want to modify. Click on the **Submit** button.

The following screen appears.



To modify Volume Set attribute values, select an attribute item and click on the attribute value. After completing the modification, tick on the **Confirm The Operation** option and click on the **Submit** button to save the changes.


5.3.4.1 Volume Set Expansion

Volume Capacity (Logical Volume Concatenation Plus Re-stripe)

Use the Expand Raid Set function to expand a Raid Set when a disk is added to your subsystem. (Refer to Section 5.2.3)

The expanded capacity can be used to enlarge the Volume Set size or create another Volume Set. Use the Modify Volume Set function to expand the Volume Set capacity. Select the Volume Set and move the cursor to the **Volume Set Capacity** item and enter the capacity size.

Tick on the **Confirm The Operation** and click on the **Submit** button to complete the action. The Volume Set starts to expand.



The screenshot shows the proRAID Manager application window. On the left is a tree view with categories like 'Raid System Console', 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', and 'Information'. The 'Volume Set Functions' category is expanded, showing options like 'Create Volume Set', 'Create Raid30/50/60', 'Delete Volume Set', 'Modify Volume Set', 'Check Volume Set', 'Schedule Volume Check', and 'Stop Volume Check'. The 'Modify Volume Set' option is selected. The main area displays the 'Enter The Volume Attribute' dialog box. It contains several fields: 'Volume Name' (Volume---VOL#000), 'Max Capacity Allowed' (7001.4 GB), 'Volume Capacity' (16000.0 GB, highlighted with a red box), 'Volume Initialization Mode' (Foreground Initialization), 'Volume Raid Level' (Raid 5), 'Volume Stripe Size' (64 KBytes), 'Volume Cache Mode' (Write Back), 'Tagged Command Queuing' (Enabled), and 'SAS Port:LUN Base:LUN' (0 : 0 : 0). At the bottom of the dialog, there is a checkbox labeled 'Confirm The Operation' and two buttons: 'Submit' and 'Reset'.



NOTE: The Volume Set capacity of Raid30/50/60 cannot be expanded.

5.3.4.2 Volume Set Migration

Migration occurs when a Volume Set migrates from one RAID level to another, a Volume Set stripe size changes, or when a disk is added to a Raid Set. Migrating status is displayed in the Volume Set status area of the RaidSet Hierarchy screen during migration.



NOTE: The Stripe Size of a Raid30/50/60 Volume Set cannot be modified.

5.3.5 Check Volume Set


Use this function to perform Volume Set consistency check, which verifies the correctness of redundant data (data blocks and parity blocks) in a Volume Set. This basically means computing the parity from the data blocks and comparing the results to the contents of the parity blocks, or computing the data from the parity blocks and comparing the results to the contents of the data blocks.



NOTE: The Volume Set state must be Normal in order to perform Check Volume Set. Only RAID levels with parity (redundant data) such as RAID Levels 3, 5, 6, 30, 50 and 60, support this function.

To perform Check Volume Set function:

1. Click on the **Check Volume Set** link.
2. Tick from the list the Volume Set you want to check. Select the Check Volume Set options.



Check Volume Set Options:

- **Scrub Bad Block If Bad Block Found, Assume Parity Data is Good**
- **Re-compute Parity if Parity Error, Assume Data is Good**



NOTE: When the 2 options are not selected, it will only check for errors. It is recommended to perform Check Volume Set with the 2 options unselected at first. If the result shows error, the two options can be selected and redo Check Volume Set to correct the errors.

3. Tick on **Confirm The Operation** and click on the **Submit** button. The Checking process will be started.

The checking percentage can also be viewed by clicking on RaidSet Hierarchy in the Information menu.

The screenshot shows the proRAID Manager application window. On the left is a tree view with categories like 'Raid System Console', 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', and 'Information'. Under 'Information', 'RAID Set Hierarchy' is selected. The main area displays a table titled 'RaidSet Hierarchy' with columns: RAID Set, Devices, Volume Set(Port/Lun), Volume State, and Capacity. The first row shows 'Raid Set # 000' with devices E#1Slot#1 through E#1Slot#8. The 'Volume State' for E#1Slot#1 is 'Checking(0.0%)'. Below this is another table titled 'Enclosure#1 : SAS RAID Subsystem V1.0' with columns: Device, Usage, Capacity, and Model. It lists five slots, each containing a Hitachi HDE721010SLA330 drive with a capacity of 1000.2GB.

RAID Set	Devices	Volume Set(Port/Lun)	Volume State	Capacity
Raid Set # 000	E#1Slot#1	Volume--VOL#000(0/0)	Checking(0.0%)	7001.4GB
	E#1Slot#2			
	E#1Slot#3			
	E#1Slot#4			
	E#1Slot#5			
	E#1Slot#6			
	E#1Slot#7			
	E#1Slot#8			

Device	Usage	Capacity	Model
Slot#1 (0:2)	Raid Set # 000	1000.2GB	Hitachi HDE721010SLA330
Slot#2 (0:C)	Raid Set # 000	1000.2GB	Hitachi HDE721010SLA330
Slot#3 (0:3)	Raid Set # 000	1000.2GB	Hitachi HDE721010SLA330
Slot#4 (0:1)	Raid Set # 000	1000.2GB	Hitachi HDE721010SLA330
Slot#5 (0:B)	Raid Set # 000	1000.2GB	Hitachi HDE721010SLA330


5.3.6 Schedule Volume Check

To perform Check Volume Set by schedule, follow these steps:

1. Click on the **Schedule Volume Check** link.
2. Select the desired schedule that you wish the Check Volume Set function to run.
Tick on **Confirm The Operation** and click on the **Submit** button.

Scheduler: Disabled, 1Day (For Testing), 1Week, 2Weeks, 3Weeks, 4Weeks, 8Weeks, 12Weeks, 16Weeks, 20Weeks and 24Weeks.

Check After System Idle: No, 1 Minute, 3 Minutes, 5 Minutes, 10 Minutes, 15 Minutes, 20 Minutes, 30 Minutes, 45Minutes and 60 Minutes.




NOTE: To verify the Volume Check schedule, go to Information -> RAID Set Hierarchy -> select the Volume Set -> the Volume Set Information will be displayed.

■ Volume Set Information	
Volume Set Name	Volume---VOL#000
Raid Set Name	Raid Set # 000
Volume Capacity	7001.4GB
SAS Port/Lun	0/0
Raid Level	Raid 5
Stripe Size	64KBytes
Block Size	512Bytes
Member Disks	8
Cache Mode	Write Back
Tagged Queuing	Enabled
Volume State	Normal
Time To Volume Check	0:23:59:6

5.3.7 Stop Volume Check

Use this option to stop current running Check Volume Set process.



5.4 Physical Drive

Choose this option from the Main Menu to select a disk drive and to perform the functions listed below.

5.4.1 Create Pass-Through Disk

A Pass-Through Disk is a disk drive not controlled by the internal RAID subsystem firmware and thus cannot be a part of a Volume Set. A Pass-Through disk is a separate and individual Raid Set. The disk is available to the host as an individual disk. It is typically used on a system where the operating system is on a disk not controlled by the RAID firmware.

To create pass-through disk, click on the **Create Pass-Through** link under the Physical Drives main menu. The setting function screen appears.

Select the disk drive to be made as Pass-Through Disk and configure the Pass-Through Disk attributes, such as the Cache Mode, Tagged Command Queuing, and SAS Port/LUN Base/LUN for this volume.


The screenshot displays the proRAID Manager web interface. The left sidebar contains a tree view with the following items: Raid System Console, Quick Function, RAID Set Functions, Volume Set Functions, Physical Drives (expanded), Create Pass-Through Disk (selected), Modify a Pass-Through Disk, Delete Pass-Through Disk, Identify Enclosure, Identify Drive, System Controls, and Information. The main content area is titled 'Select the IDE drive For Pass Through' and shows 'Enclosure#1 : SAS RAID Subsystem V1.0'. Below this, a table lists available drives: Slot#8, 1000.2GB, WDC WD10EARS-00Y5B1. The 'Enter Pass Through Disk Attribute' section includes: Volume Cache Mode (Write Back), Tagged Command Queuing (Enabled), and SAS Port:LUN Base:LUN (0 : 0 : 1). At the bottom, there is a 'Confirm The Operation' checkbox and 'Submit' and 'Reset' buttons.

5.4.2 Modify a Pass-Through Disk

Use this option to modify the attribute of a Pass-Through Disk. User can modify the Cache Mode, Tagged Command Queuing, and SAS Port/LUN Base/LUN on an existing Pass-Through Disk.


To modify the Pass-Through drive attribute from the Pass-Through drive pool, click on the **Modify a Pass-Through Disk** link. The "Select The Pass-Through Disk For Modification" screen appears. Tick on the Pass-Through Disk from the Pass-Through drive pool and click on the **Submit** button to select the drive.

The Enter Pass-Through Disk Attribute screen appears. Modify the drive attribute values as you want.




5.4.3 Delete Pass-Through Disk

To delete Pass-Through Disk from the Pass-Through drive pool, click on **Delete Pass-Through** link. Select a Pass-Through Disk, tick on the **Confirm The Operation** and click the **Submit** button to complete the delete action.



5.4.4 Identify Enclosure


To identify an Enclosure, move the mouse cursor and click on **Identify Enclosure** link. The **Select The Enclosure For Identification** screen appears. Tick on the enclosure from the list of enclosures, then click on the **Submit** button to identify the selected enclosure. All disk drives' Status LEDs in an enclosure will be blinking when a particular enclosure is selected.



5.4.5 Identify Selected Drive

Use this option to physically locate a selected drive to prevent removing the wrong drive. When a disk drive is selected using the **Identify Drive** function, the Status LED of the selected disk drive will be blinking Red.


To identify a selected drive from the drives pool, click on the **Identify Drive** link. The “Select The IDE Device For identification” screen appears. Tick on the IDE device from the drives list. After completing the selection, click on the **Submit** button to identify selected drive.



5.5 System Controls

5.5.1 System Configuration

To set the RAID subsystem system configuration options, click the **System Configuration** link under the **System Controls** menu. The System Configurations screen will be shown. Set the desired system option as needed.



System Configurations	
System Beeper Setting	Enabled
Background Task Priority	High(80%)
JBOD/RAID Configuration	RAID
SATA NCQ Support	Disabled
HDD Read Ahead Cache	Enabled
Volume Data Read Ahead	Normal
HDD Queue Depth	32
Disk Write Cache Mode	Enabled
Disk Capacity Truncation Mode	Multiples Of 1G

☐ Confirm The Operation

Submit Reset

System Beeper Setting:

This option is used to Disable or Enable the system's RAID controller alarm beeper.

Background Task Priority:

The Background Task Priority indicates how much time and system resource the RAID controller devotes to a background task, such as a rebuild operation. The RAID subsystem allows user to choose the background task priority (High 80%, Medium 50%, Low 25%, and Ultra Low 5%) to balance between background task process and Volume Set access. For high RAID subsystem performance, specify a low value.

JBOD/RAID Configuration:

The RAID subsystem supports JBOD and RAID configuration.

SATA NCQ Support:

NCQ is a command protocol in Serial ATA that can only be implemented on native Serial ATA hard drives. It allows multiple commands to be outstanding within a drive at the same time. Drives that support NCQ have an internal queue where outstanding commands can be dynamically rescheduled or re-ordered, along with the necessary tracking mechanisms for outstanding and completed portions of the workload. Disabled or Enable the SATA NCQ function.

HDD Read Ahead Cache:

This option allows the users to disable the cache of the HDDs on the RAID subsystem. In some HDD models, disabling the cache in the HDD is necessary to prove the RAID subsystem functions correctly.

Volume Data Read Ahead:

This option allows the users to set the Volume Data Read Ahead function. Options are: Normal, Aggressive, Conservative, and Disabled.

HDD Queue Depth:

The queue depth is the number of I/O operations that can be run in parallel on a disk drive. HDD Queue Depth options are 1, 2, 4, 8, 16, and 32.

Disk Write Cache Mode:

The RAID subsystem supports Disk Write Cache Mode options: Auto, Enabled, and Disabled. If the RAID subsystem has BBM (battery backup module), selecting the Auto option will automatically enable Disk Write Cache. On the other hand, if there is no BBM, the Auto option will disable Disk Write Cache.

Disk Capacity Truncation Mode:

The RAID subsystem use drive truncation so that drives from different vendors are more likely to be able to be used as spares for each other. Drive truncation slightly decreases the usable capacity of a drive that is used in redundant units. Options are:

Multiples Of 10G: If you have several 120GB drives from different vendors, chances are that the capacity varies slightly. For example, one drive might be 121.1 GB, and the other 120.4 GB. This drive truncation mode makes the 121.1 GB and 120.4 GB drives same capacity as 120 GB so that one could replace the other.

Multiples Of 1G: If you have 120 GB drives from different vendors, chances are that the capacity varies slightly. For example, one drive might be 121.1 GB, and the other 121.4 GB. This drive truncation mode makes the 121.1 GB and 121.4 GB drives same capacity 121 GB so that one could replace the other.

No Truncation: The capacity of the disk drive is not truncated.

5.5.2 HDD Power Management


MAID (**M**assive **A**rray of **I**dle **D**isks) is a storage technology that employs a large group of disk drives in which only those drives in active use are spinning at any given time.

This reduces power consumption and prolongs the lives of the drives.

MAID is designed for Write Once, Read Occasionally (WORO) applications such as Data Backup, Document, Mail server, and so on.

MAID technology focuses on "Green Storage Concept" to save power consumption and enhance disk drives effective usage, i.e., "disk drives are spun down when there is no activity or I/O on the drives".

In the RAID subsystem, MAID is implemented in the **HDD Power Management** menu. Using the **Advanced Power Management (APM)** function of disk drives, HDD Power Management has three options (MAID Levels): (Level 1) Place idle drives in Lower Power Mode, where the drives' heads are unloaded; (Level 2) Place idle drives in Low RPM Mode, where drives' heads are unloaded and slows down to around 4000 RPM; and (Level 3) Spin down idle drives, where drives stops spinning and goes into sleep mode.



Stagger Power On Control:

This option allows the RAID subsystem's power supply to power up in succession each HDD in the RAID subsystem. In the past, all the HDDs on the RAID subsystem are powered up altogether at the same time. This function allows the power transfer time (lag time) from the last HDD to the next one be set within the range of 0.4 to 6.0 seconds. Default is 0.7 seconds.

Time to HDD Low Power Idle: (MAID Level 1)

This option enables the RAID subsystem to place idle HDDs of a Raid Set in Low Power Mode, where drives' heads are unloaded. The power consumption of the Idle HDD saving is around 15% to 20%. Recovery time is under a second.

Options are: Disabled, 2, 3, 4, 5, 6, and 7 (Minutes).

Time to HDD Low RPM Mode: (MAID Level 2)

This option enables the RAID subsystem to place idle HDDs of a Raid Set in Low RPM Mode, where drives' heads are unloaded and drive platters speed is reduced to around 4000 RPM. The power consumption of the Idle HDD saving is from 35% to 45%. Recovery time is 15 seconds.

Options are: Disabled, 10, 20, 30, 40, 50, and 60 (Minutes).

Time to Spin Down Idle HDD: (MAID Level 3)

This option enables the Raid subsystem to spin down HDDs of a Raid Set after they become idle after a preset period of time. In this level, the drives stop spinning and go into sleep mode. The power consumption of the Idle HDD saving is from 60% to 70%. Recovery time is 30 to 45 seconds.

Options are: Disabled, 1 (For Test), 3, 5, 10, 15, 20, 30, 40, and 60 (Minutes).



NOTE: To verify if the disk drive you use supports MAID or APM, select "RaidSet Hierarchy" and click the disk drive (E# Slot#) link. Check in the Device Information screen if the Disk APM Support shows "Yes".

5.5.3 EtherNet Configuration

To set the Ethernet configuration, click the **EtherNet Configuration** link under the System Controls menu. The RAID subsystem EtherNet Configuration screen will be shown. Set the desired configuration. Once done, tick on the **Confirm The Operation** and click the **Submit** button to save the settings.

proRAID Manager XXXXXXXXXXXXXXXX

[open all|close all]

- Raid System Console
 - Quick Function
 - RAID Set Functions
 - Volume Set Functions
 - Physical Drives
 - System Controls
 - System Configuration
 - Hdd Power Management
 - EtherNet Configuration**
 - Alert By Mail Configuration
 - SNMP Configuration
 - NTP Configuration
 - View Events/Mute Beeper
 - Generate Test Event
 - Clear Event Buffer
 - Modify Password
 - Upgrade Firmware
 - Shutdown Controller
 - Restart Controller
 - Information

Ether Net Configurations

DHCP Function	Enabled
Local IP Address (Used If DHCP Disabled)	192 . 168 . 1 . 100
Gateway IP Address (Used If DHCP Disabled)	192 . 168 . 1 . 1
Subnet Mask (Used If DHCP Disabled)	255 . 255 . 255 . 0
HTTP Port Number (7168..8191 Is Reserved)	80
Telnet Port Number (7168..8191 Is Reserved)	23
SMTP Port Number (7168..8191 Is Reserved)	25
Current IP Address	192.168.1.100
Current Gateway IP Address	192.168.1.1
Current Subnet Mask	255.255.255.0
Ether Net MAC Address	00.1B.4D.01.50.3F

☐ **Confirm The Operation**

Submit Reset



NOTE: If HTTP, Telnet and SMTP Port Number is set to "0", the service is disabled.

5.5.4 Alert By Mail Configuration

To set the Event Notification function, click on the **Alert By Mail Configuration** link under the System Controls menu. The RAID subsystem Event Notification configuration screen will be shown. Set up the desired function and option. When an abnormal condition occurs, an error message will be emailed to the email recipient(s) that a problem has occurred. Events are classified into 4 levels (Urgent, Serious, Warning, and Message).

proRAID Manager xxxxxxxxxxxxxx

open all | close all

- Raid System Console
- Quick Function
- RAID Set Functions
- Volume Set Functions
- Physical Drives
- System Controls
 - System Configuration
 - Hdd Power Management
 - EtherNet Configuration
 - Alert By Mail Configuration**
 - SNMP Configuration
 - NTP Configuration
 - View Events/Mute Beeper
 - Generate Test Event
 - Clear Event Buffer
 - Modify Password
 - Upgrade Firmware
 - Shutdown Controller
 - Restart Controller
- Information

SMTP Server Configuration

SMTP Server IP Address: [0][0][0][0]

Mail Address Configurations

Sender Name: [] Mail Address: []

Account: [] Password: []

Event Notification Configurations

MailTo Name1: [] Mail Address: []

- ☒ Disable Event Notification: No Event Notification Will Be Sent
- ☐ Urgent Error Notification: Send Only Urgent Event
- ☐ Serious Error Notification: Send Urgent And Serious Event
- ☐ Warning Error Notification: Send Urgent, Serious And Warning Event
- ☐ Information Notification: Send All Event
- ☐ Notification For No Event: Notify User If No Event Occurs Within 24 Hours

MailTo Name2: [] Mail Address: []

- ☒ Disable Event Notification: No Event Notification Will Be Sent
- ☐ Urgent Error Notification: Send Only Urgent Event
- ☐ Serious Error Notification: Send Urgent And Serious Event
- ☐ Warning Error Notification: Send Urgent, Serious And Warning Event
- ☐ Information Notification: Send All Event
- ☐ Notification For No Event: Notify User If No Event Occurs Within 24 Hours

MailTo Name3: [] Mail Address: []

- ☒ Disable Event Notification: No Event Notification Will Be Sent
- ☐ Urgent Error Notification: Send Only Urgent Event
- ☐ Serious Error Notification: Send Urgent And Serious Event
- ☐ Warning Error Notification: Send Urgent, Serious And Warning Event
- ☐ Information Notification: Send All Event
- ☐ Notification For No Event: Notify User If No Event Occurs Within 24 Hours

MailTo Name4: [] Mail Address: []

- ☒ Disable Event Notification: No Event Notification Will Be Sent
- ☐ Urgent Error Notification: Send Only Urgent Event
- ☐ Serious Error Notification: Send Urgent And Serious Event
- ☐ Warning Error Notification: Send Urgent, Serious And Warning Event
- ☐ Information Notification: Send All Event
- ☐ Notification For No Event: Notify User If No Event Occurs Within 24 Hours



NOTE: If Event Notification by email is enabled, every 30 of event log will be sent to the email recipient(s) as one package log.



NOTE: If different email recipients are setup, the event notification levels for each email recipient can be configured differently. For example, first email recipient can be configured with "Urgent Error Notification" while second email recipient can be configured with "Serious Error Notification".

5.5.5 SNMP Configuration

The SNMP gives users independence from the proprietary network management schemes of some manufacturers and SNMP is supported by many WAN and LAN manufacturers enabling true LAN/ WAN management integration.

To set the SNMP function, move the cursor to the main menu and click on the **SNMP Configuration** link. The RAID subsystem's SNMP Configurations screen will be shown. Select the desired function and set the preferred option.

■ SNMP Trap Configurations		
SNMP Trap IP Address #1	0 . 0 . 0 . 0	Port# 162
SNMP Trap IP Address #2	0 . 0 . 0 . 0	Port# 162
SNMP Trap IP Address #3	0 . 0 . 0 . 0	Port# 162

■ SNMP System Configurations	
Community	
sysContact.0	
sysName.0	
sysLocation.0	

■ SNMP Trap Notification Configurations	
<input checked="" type="radio"/> Disable SNMP Trap	No SNMP Trap Will Be Sent
<input type="radio"/> Urgent Error Notification	Send Only Urgent Event
<input type="radio"/> Serious Error Notification	Send Urgent And Serious Event
<input type="radio"/> Warning Error Notification	Send Urgent, Serious And Warning Event
<input type="radio"/> Information Notification	Send All Event

☐ Confirm The Operation

SNMP Trap Configurations: Type in the SNMP Trap IP Address box the IP address of the host system where SNMP traps will be sent. The SNMP Port is set to 162 by default.

SNMP System Configuration:

Community: Type the SNMP community. The default is public.

(1) **sysContact.0**, (2) **sysLocation.0**, and (3) **sysName.0**: SNMP parameter (31 bytes max). If these 3 categories are configured and when an event occurs, SNMP will send out a message that includes the 3 categories within the message. This allows user to easily define which RAID unit is having problem.

SNMP Trap Notification Configurations: Select the desired option.

After completing the settings, tick on the **Confirm The Operation** and click on the **Submit** button to save the configuration.

SNMP also works in the same as Alert By Mail when sending event notifications.

5.5.6 NTP Configuration

NTP stands for **Network Time Protocol**. It is an Internet protocol used to synchronize the clocks of computers to some time reference. Type the NTP Server IP Address to enable the RAID subsystem to synchronize with it.

To set the NTP function, move the cursor to the main menu and click on the **NTP Configuration** link. The RAID subsystem's NTP Configuration screen will be displayed. Select the desired function and configure the necessary option.

After completing the settings, tick on the **Confirm The Operation** and click on the **Submit** button to save the configuration.

proRAID Manager XXXXXXXXXXXXXXXX

|open all|close all|

- Raid System Console
- Quick Function
- RAID Set Functions
- Volume Set Functions
- Physical Drives
- System Controls
 - System Configuration
 - Hdd Power Management
 - EtherNet Configuration
 - Alert By Mail Configuration
 - SNMP Configuration
 - NTP Configuration**
 - View Events/Mute Beeper
 - Generate Test Event
 - Clear Event Buffer
 - Modify Password
 - Upgrade Firmware
 - Shutdown Controller
 - Restart Controller
- Information

■ NTP Server Configurations

NTP Server IP Address #1 [0].[0].[0].[0]

NTP Server IP Address #2 [0].[0].[0].[0]

■ Time Zone Configuration

Time Zone : (GMT+08:00)Taipei

Automatic Daylight Saving : Enabled

Current Time : 2009/4/20 19:33:29

NTP Server Not Set


☐ Confirm The Operation

Submit Reset

5.5.7 View Events / Mute Beeper

To view the RAID subsystem's event log information, move the mouse cursor to the System Controls menu and click on the **View Events/Mute Beeper** link. The Raid Subsystem's System Events Information screen appears.

The System Events Information screen will show: Time, Device, Event type, Elapse Time and Errors.




The screenshot shows the proRAID Manager application window. The title bar reads "proRAID Manager" followed by a series of "X" characters. The left sidebar contains a tree view with categories like "Raid System Console", "Quick Function", "RAID Set Functions", "Volume Set Functions", "Physical Drives", and "System Controls". The "View Events/Mute Beeper" option is highlighted under "System Controls". The main area displays a table titled "System Events Information" with columns for Time, Device, Event Type, Elapse Time, and Errors. The table contains 15 rows of event logs.

Time	Device	Event Type	Elapse Time	Errors
2010-05-25 13:22:05	Enc#1 Slot#8	PassThrough Disk Created		
2010-05-25 13:14:28	Volume---VOL#000	Start Initialize		
2010-05-25 13:14:26	Volume---VOL#000	Create Volume		
2010-05-25 12:00:30	Raid Set # 001	Create RaidSet		
2010-05-25 12:00:24	Raid Set # 000	Create RaidSet		
2010-05-25 12:00:16	Raid Set # 000	Delete RaidSet		
2010-05-25 11:58:04	Raid Set # 000	Create RaidSet		
2010-05-25 11:57:50	Raid Set # 000	Delete RaidSet		
2010-05-25 11:56:49	Raid Set # 000	Create RaidSet		
2010-05-25 11:56:42	Raid Set # 000	Delete RaidSet		
2010-05-25 11:43:11	Raid Set # 000	Expand RaidSet		
2010-05-25 11:42:40	Raid Set # 000	Create RaidSet		
2010-05-25 11:42:33	Raid Set # 000	Delete RaidSet		

This function is also used to silence the beeper alarm.


5.5.8 Generate Test Event

If you want to generate test events, move the cursor bar to the main menu and click on the **Generate Test Event** Link. Tick on the **Confirm The Operation** and click on the **Submit** button. Then click on the **View Events/Mute Beeper** to view the test event.



5.5.9 Clear Event Buffer

Use this feature to clear the RAID subsystem's System Events Information buffer.




5.5.10 Modify Password

To change or disable the RAID subsystem's admin password, click on the **Modify Password** link under the **System Controls** menu. The Modify System Password screen appears.

The factory-default admin password is set to **00000000**. Once the password has been set, the user or administrator can only monitor and configure the RAID subsystem by providing the correct password.

The password is used to protect the RAID subsystem's configuration from unauthorized access. The RAID controller will check the password only when entering the Main Menu from the initial screen. The RAID subsystem will automatically go back to the initial screen when it does not receive any command after sometime.

To disable the password, enter only the original password in the **Enter Original Password** box, leave both the **Enter New Password** and **Re-Enter New Password** boxes blank. After selecting the **Confirm The Operation** option and clicking the **Submit** button, the system password checking will be disabled. No password checking will occur when entering the main menu from the starting screen.



The screenshot shows the proRAID Manager web interface. The title bar displays 'proRAID Manager' and a series of 'X' characters. The left sidebar contains a tree view with categories like 'Raid System Console', 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', and 'Information'. Under 'System Controls', 'Modify Password' is highlighted. The main content area shows the 'Modify System Password' form with three input fields: 'Enter Original Password', 'Enter New Password', and 'Re-Enter New Password'. Below these fields is a checkbox labeled 'Confirm The Operation' and two buttons: 'Submit' and 'Reset'.



NOTE: The admin Password characters allowed are 'A' – 'Z', 'a' – 'z', and '0' – '9'. The minimum number of Password characters is null/empty (Password is disabled) and maximum number of Password characters is 15.


5.5.11 Upgrade Firmware

Get the new version of firmware for your RAID subsystem controller.




NOTE: When there is new boot ROM firmware that needs to be upgraded, upgrade first the boot ROM firmware. Then repeat the process (steps 1 to 3) to upgrade the firmware code after which a RAID controller restart will be necessary.

1. To upgrade the RAID subsystem firmware, click the **Upgrade Firmware** link under **System Controls** menu. The Upgrade The Raid System Firmware Or Boot Rom screen appears.
2. Click **Browse**. Look in the location where the firmware file was saved. Select the firmware file name "XXXXXXXXX.BIN" and click Open.
3. Select the **Confirm The Operation** option. Click the **Submit** button.





4. The Web Browser begins to download the firmware binary to the controller and start to update the flash ROM.

5. After the firmware upgrade is complete, a message will show "Firmware Has Been Updated Successfully". Restarting the RAID controller is required for the new firmware to take effect.



5.5.12 Shutdown Controller



Use this function to shutdown the RAID Controller. This is normally used to make sure the data in the cache memory are flushed to the disk drives before turning off the RAID subsystem.



After shutting down the controller and still want to use the RAID subsystem, you must restart the controller either by Restart Controller function or by Power On/Off switch.

5.5.13 Restart Controller

Use this function to restart the RAID Controller. This is normally used after upgrading the RAID controller's firmware.



5.6 Information Menu

5.6.1 RAID Set Hierarchy

Use this feature to view the RAID subsystem's existing Raid Set(s), Volume Set(s) and disk drive(s) configuration and information. Select the **RAID Set Hierarchy** link from the **Information** menu to display the Raid Set Hierarchy screen.


RAID Set	Devices	Volume Set(Port/Lun)	Volume State	Capacity
Raid Set # 000	E#1Slot#1	Volume---VOL#000(0/0)	Normal	2199.0GB
	E#1Slot#2			
	E#1Slot#3			
	E#1Slot#4			
	E#1Slot#5			
	E#1Slot#6			
Raid Set # 001	E#1Slot#7	Volume---VOL#001(1/0)	Normal	2199.0GB
	E#1Slot#8			
	E#1Slot#9			
	E#1Slot#10			
	E#1Slot#11			
	E#1Slot#12			

Device	Usage	Capacity	Model
Slot#1(12)	Raid Set # 000	600.1GB	WDC WD6000HLHX-0113PV0
Slot#2(13)	Raid Set # 000	600.1GB	WDC WD6000HLHX-0113PV0
Slot#3(10)	Raid Set # 000	600.1GB	WDC WD6000HLHX-0113PV0
Slot#4(1E)	Raid Set # 000	600.1GB	WDC WD6000HLHX-0113PV0
Slot#5(14)	Raid Set # 000	600.1GB	WDC WD6000HLHX-0113PV0
Slot#6(15)	Raid Set # 000	600.1GB	WDC WD6000HLHX-0113PV0
Slot#7(1B)	Raid Set # 001	600.1GB	WDC WD6000HLHX-0113PV0
Slot#8(1C)	Raid Set # 001	600.1GB	WDC WD6000HLHX-0113PV0
Slot#9(16)	Raid Set # 001	600.1GB	WDC WD6000HLHX-0113PV0
Slot#10(17)	Raid Set # 001	600.1GB	WDC WD6000HLHX-0113PV0
Slot#11(18)	Raid Set # 001	600.1GB	WDC WD6000HLHX-0113PV0
Slot#12(19)	Raid Set # 001	600.1GB	WDC WD6000HLHX-0113PV0


To view the Raid Set information, click the **Raid Set #** link from the Raid Set Hierarchy screen. The Raid Set Information screen appears.

RAID Set Information	
Raid Set Name	Raid Set # 000
Member Disks	8
Total Raw Capacity	8001.6GB
Free Raw Capacity	0.0GB
Min Member Disk Size	1000.2GB
Raid Set Power State	Operating
Raid Set State	Normal

To view the disk drive information, click the **Slot#** link from the Raid Set Hierarchy screen. The Disk Information screen appears. This screen shows various information such as timeout count, media error count, and SMART information.




To view the Volume Set information, click the **Volume---VOL#** link from the Raid Set Hierarchy screen. The Volume Set Information screen appears.



5.6.2 System Information

To view the RAID subsystem's controller information, click the **System Information** link from the **Information** menu. The Raid Subsystem Information screen appears.



The screenshot shows the RAID Subsystem Information screen. On the left is a sidebar with a tree view containing the following items: 'Raid System Console', 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', 'Information' (expanded), 'RAID Set Hierarchy', 'System Information' (selected), and 'Hardware Monitor'. The main area displays a table titled 'Raid Subsystem Information' with the following data:

Raid Subsystem Information	
Controller Name	
Firmware Version	V1.49 2010-12-10
BOOT ROM Version	V1.49 2010-12-10
PL Firmware Version	7.0.0.0
Serial Number	A052EHCOPR600003
Unit Serial #	
Main Processor	800MHz PPC440
CPU ICache Size	32KBytes
CPU DCache Size	32KBytes/Write Back
System Memory	2048MB/800MHz/ECC
Current IP Address	192.168.15.201
SAS Address	5001B4D0189B7800
SAS Port0 Link Status	4x600MB/Sec
SAS Port1 Link Status	4x600MB/Sec

The Controller Name, Firmware Version, Boot ROM version, PL Firmware Version, Serial Number, Unit Serial #, Main Processor, CPU ICache Size, CPU DCache Size, System Memory, Current IP Address, SAS Address, SAS Port0 Link Status, and SAS Port1 Link Status appear in this screen.

5.6.3 Hardware Monitor

To view the RAID subsystem's hardware information, click the **Hardware Monitor** link from the **Information** menu. The Hardware Monitor Information screen appears.

The screenshot shows the 'Hardware Monitor' window. On the left is a tree view with the following items: 'Raid System Console', 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', 'Information', 'RAID Set Hierarchy', 'System Information', and 'Hardware Monitor' (which is selected). The main area on the right contains a 'Stop Auto Refresh' checkbox and two sections of data.

Controller H/W Monitor

CPU Temperature	43 °C
Controller Temp.	38 °C
12V	12.038 V
5V	5.053 V
3.3V	3.344 V
DDR-II +1.8V	1.824 V
CPU +1.8V	1.840 V
CPU +1.2V	1.264 V
CPU +1.0V	1.040 V
DDR-II +0.9V	0.912 V
RTC 3.0V	3.312 V
Battery Status	Not Installed

Enclosure# 1 : SAS RAID Subsystem V1.0

Voltage#1	3.376 V
Voltage#2	5.040 V
Voltage#3	11.996 V
Fan#1	3245 RPM
Fan#2	2596 RPM
Power#1	OK
Power#2	OK
UPS Status	OK
Temperature#1	31 °C
Temperature#2	30 °C
Temperature#3	30 °C
Temperature#4	32 °C
Temperature#5	30 °C
Temperature#6	29 °C
Temperature#7	30 °C
Temperature#8	32 °C
Temperature#9	30 °C
Temperature#10	29 °C
Temperature#11	29 °C
Temperature#12	31 °C

The Hardware Monitor Information provides the temperature, fan speed (chassis fan) and voltage levels of the RAID subsystem. All items are also unchangeable. When the threshold values are surpassed, warning messages will be indicated through the LCD, LED and alarm buzzer.

Item	Warning Condition
CPU Temperature	> 90 Celsius
Controller Temperature	> 70 Celsius
Controller Fan Speed	< 700 RPM
Power Supply +12V	< 10.5V or > 13.5V
Power Supply +5V	< 4.7V or > 5.4V
Power Supply +3.3V	< 3.0V or > 3.6V
DDR Supply Voltage +2.5V	< 2.25V or > 2.75V
CPU Core Voltage +1.3V	< 1.17V or > 1.43V
DDR Termination Power +1.25V	< 1.125V or > 1.375V